



[www.LessLoss.com](http://www.LessLoss.com)

# Firewall

## POWER CONDITIONING UNIT

Dear LessLoss Firewall owner,

Operating instructions for the Firewall include the following:

### (1) Proper Connection

When connecting power to the **Firewall** through the DFPC Signature, please make absolutely certain that the Live wire from your wall is going through the Live wire of the DFPC Signature, and into the hole in the IEC connector at the end of the DFPC Signature which is marked with the letter "L". Likewise, when you connect the **Firewall** in this manner, please make sure that the Schuko wall outlet of the **Firewall** has the Live signal coming out of the hole which is marked "Line" on the Schuko wall type outlet, or is the smaller of the two slits in the USA/Japan wall type outlet. Please do not experiment with the N and L connections by ear, but ensure that they are correct for each LessLoss cable and **Firewall** separately.

### (2) Proper Setup

For best audible results, it is recommended to place the **Firewall** on all three of its feet, on a horizontal, hard surface, instead of on a soft, long-haired rug or rubbery surface. Please avoid exposure to direct sunlight.

### (3) Settling in period and sound quality

The **Firewall's** settling in period can be very pronounced, according to system resolution. Please expect at least 5 days to pass, using the **Firewall** daily, for the sound to open up. It is normal that this period of changing sound can extend for upwards of two weeks.

Regards,  
Louis Motek

LessLoss Audio  
[www.LessLoss.com](http://www.LessLoss.com)