


This unit conditions the current for ONLY ONE polarity. Thus it is sold as a stereo set of four units so you could condition Left Positive, Left Negative, Right Positive, and Right Negative polarities.

Load is your speaker load (the drivers).
Source is your amp's supply of signal.
Note red tips to determine polarity and relationship between source and load.



Pinch all four extending copper rods of each polarity's end together around your flexible lead and solder your lead to all four ends simultaneously. This is 16mm², a large iron is recommended. (We use 150 Watts.) Simply solder over the red markings; they will not interfere. Use ample flux. This copper is highly treated. Oxides are normal and per design.